

**Universal Moulds cont...**

**UNI-6**

**REAR**

Universal rear screen mould. Suits Hyundai Excel, late model & other rears, Holden VT sedan rear upper mould (upside down)

**25m Roll**

**UNI-6A**

**REAR**

Wider version of UNI-6. Same as UNI-8 but for 3mm glass.

**25m Roll**

**UNI-11**

**REAR**

VT Commodore rear lower mould.

**25m Roll**

**UNI-15**

**REAR**

VT Commodore wagon rear mould & other vehicle rear windows.

**25m Roll**

**OZ-BLOCK**

Setting block

**5m Roll**

**TP-566**

05- Hilux mould, 100 series top.

**25m Roll**

**POPULAR**

**TP-756**

PVC Universal Mould with Butyl. 100 series top & Toyota Starlet.

**25m Roll**

**OZ-CHROME-RL2.8**

Holden Statesman SV21, Camry & others.

**2.8m Length**

**NEW**

**OZ-FT38**

Western Star Centre Bar Up to 16 screens per length

**10m Length**

**Self-Adhesive Sponge Seals**

Good for canopies, hatches, toolboxes and other various applications.

**OZ-50110-RL50**

**NEW**

EPDM Sponge 50m Roll

**OZ-50110**

**OZ-50109-RL33**

EPDM Sponge 33m Roll

**OZ-50109**

**OZ-135AT-RL33**

EPDM Sponge 33m Roll

**OZ-135AT**

**OZ-019-RL66**

EPDM Sponge 66m Roll

**POPULAR**

**OZ-019**

**OZ-50449-RL33**

EPDM Sponge 33m Roll

**POPULAR**

**OZ-50449**

**OZ-5036-2-RL33**

EPDM Sponge 33m Roll

**OZ-5036-2**

**OZ-TP95-RL50**

TPR 50m Roll

**OZ-TP95**

**OZ-TGSEAL-RL33**

EPDM Sponge 33m Roll

**OZ-TGSEAL**

Used as general purpose rubber seals Comes with self-adhesive tape

**Pinchweld PVC Trim & Co Extrusions - 50m Rolls**



<p><b>090Z035-RL50</b></p> <p><b>Grip Range:</b> 0.5 - 2.0mm</p> <p>✦ BULLBAR EDGE PROTECTOR</p> <p><b>090Z035</b></p>	<p><b>090Z056-RL50</b></p> <p><b>Grip Range:</b> 1.0 - 3.5mm</p> <p>✦ EDGE PROTECTIVE TRIM</p> <p><b>090Z056</b></p>	<p><b>186N12-RL50</b></p> <p><b>Grip Range:</b> 0.8 - 3.5mm</p> <p>✦ EDGE PROTECTIVE TRIM</p> <p><b>186N12</b></p>	<p><b>090Z053-RL50</b></p> <p><b>Grip Range:</b> 0.5 - 4.0mm</p> <p>WIRE CAGE</p> <p>✦ TOOLBOX SIDE</p> <p><b>090Z053</b></p>	<p><b>090Z051-RL50</b></p> <p><b>Grip Range:</b> 0.5 - 4.0mm</p> <p>WIRE CAGE</p> <p>✦ TOOLBOX LID</p> <p><b>090Z051</b></p>
--	--	--	---	--

**Mylar - Per Metre**

<p><b>TORANA</b></p> <p><b>Use with Rubbers:</b> Torana LC, LJ, LH, LX, Corolla KE30</p>	<p><b>GEMINI</b></p> <p><b>Use with Rubbers:</b> Gemini TX-TG, Cortina TC</p>	<p><b>COMMODORE</b></p> <p><b>Use with Rubbers:</b> Commodore VB-VH, BMW E30, Early Valiant R &amp; S, VC-VF, AP5-AP6</p>	<p><b>COMMODORE-BLK</b></p> <p><b>Use with Rubbers:</b> Commodore VB-VH, BMW E30, Early Valiant R &amp; S, VC-VF, AP5-AP6</p> <p>✦ EPDM ✦ BLACK</p>
<p><b>MINI</b></p> <p><b>Use with Rubbers:</b> Mini, Kenworth Trucks</p>	<p><b>VALIANT</b></p> <p><b>Use with Rubbers:</b> Valiant VH-CM</p>	<p><b>VOLKSWAGEN</b></p> <p><b>Use with Rubbers:</b> Early Beetle, Kombi</p>	

**Checker Plate SBR Matting**

**OZ3.5-120CP-RL10**

**THICKNESS:** 3.5mm  
**WIDTH:** 1200mm  
**REINFORCED:** NONE  
**ROLL LENGTH:** 10m

**Wide Rib SBR Matting**

**OZ3.5-183WR-RL10**

**THICKNESS:** 3.5mm  
**WIDTH:** 1830mm  
**REINFORCED:** NONE  
**ROLL LENGTH:** 10m

**OZ5-183WR-RL10**

**THICKNESS:** 5mm  
**WIDTH:** 1830mm  
**REINFORCED:** COTTON  
**ROLL LENGTH:** 10m